



IDISAI camera to Trigger Output

Connect.dickerdata.co.nz







Video Analytics/IDLA

Setup the analytic detection on the camera. This will be dependent on the camera model.

- **EVENT**
- Video-Analytics
- IDLA

Select the **detection mode** and click on each section to make adjustments.








Analytics – Line Crossing

Line

- Setup line, edit name, direction
- Select **SAVE** to finish






Analytics – Line Crossing

Setup

- Ignoring interval Ignore time between triggers.
- *Ignoring Time* Schedule for ignore time.
- Leave as default if no changes are required.






Analytics – Line Crossing

Actions

 Alarm Out – Select the ouput/s that need to be triggered from this detection event





Device – Alarm-out - Schedule

Schedule

- **Dwell Time** Output runtime.

 Please Note: Dwell time is global across all outputs
- Range Schedule for event trigger.
 Leave as default if time parameters are not required.
- Mode Leave as Event.
- **Channels-** Select the outputs to trigger.






Device – Alarm-out - Schedule

Channels

- Here you can select the outputs to operate when the AI event has triggered.
- Apply when finished
- Field test the Al trigger event. Output will activate for the set time. Eg 10 sec





Output Wiring

