RF Receiver on Solution 6000

**RF120 - Up to 4 per system. Addressable between 1 - 4 via dipswitch**

Location 3-5-0 = 4

TR800-433B

4 = Bosch Serial receiver